




SeaHawk GROW TENT

2.3M HIGH 4.5 x 3M

4416












INSTRUCTION MANUAL









WHAT'S IN THE BOX








2 X BOXES

Please take the time, before assembling tent, to make sure all contents are present within this box.

- | | |
|---|---|
| <p>4 </p> <p>2 </p> <p>8 </p> <p>10 </p> <p>8 </p> <p>2 </p> | <p>29  A 142cm</p> <p>12  B 112.5cm</p> <p>12  C 112.5cm</p> <p>8  E 145.5cm</p> <p>16  F 145.5cm</p> |
|---|---|



SeaHawk TENT KEY

	ZIPPER DOOR/ ACCESS		OUTLET VENT 275" & 315"
	WINDOW		INTAKE PORT 315"
	AIR INTAKE		CABLE PORT 100"
	DRAIN OUTLET 130 X 50MM		

ASSEMBLY INSTRUCTIONS

STEP 1

Construct the metal tent frame by assembling the metal poles, corners, and connectors as per diagram. **To avoid damage, it is very important to check that all the poles are pushed completely into each corner/connector/joiner. Use a rubber mallet to gently tap fittings into the poles if necessary.**

Failure to do so will not only make the tent cover difficult to fit but may also stretch the seams and allow emissions of light from the functioning tent.

STEP 2

Un-zip top and base zipper system from the FRONT SIDE (where it has **seaHawk** logo and see-through windows) all the way to the back side of the tent. **It is important you leave the zippers on BACK SIDE closed.**

STEP 3

Locate the tents' ROOF (*Refer PIC A*) and place neatly and carefully over all 4 corners of the top frame, ensuring a snug fit.

STEP 4

Slip the base section of the tent cover beneath the assembled frame. Ensure it fits in a neat and precise manner around the tent frame corners and sides (*Refer PIC B*).

STEP 5





Carefully close the two large horizontal zipper systems simultaneously. You may have to push the upright poles in a bit as you zip around each corner (*Refer PIC C*).

STEP 6

Attach shallow/deep bars, waterproof floor trays, and pouch in place along with the Nylon fabric straps.

DISMANTLING OF SMART TENT

- 1 Ensure the tent is clean and dry before dismantling.
- 2 Reverse the operation as per above instruction. (**Step 6> Step 5> Step 4> Step 3> Step 2> Step 1**) To ensure your **Smart Tent** maintains the same "lightproof" quality, always dismantle carefully and avoid stretching the seams of the tent cover.



seaHawk is distributed in Australia by Holland Forge PTY LTD.

